

Verlegehinweise

Laying instructions



Starke Verbindung
Kluge Technik
Strong contacts
Clever technology

Vorbereitung:

Die Sockelleiste wird durch nageln, klammern oder kleben an der Wand befestigt. Die Wand und der Boden sollten möglichst plan sein. Beginnen Sie zunächst an der Türzarge und arbeiten Sie im Uhrzeigersinn.

Zuschnitt der Sockelleisten:

Zum Ende oder an / in den Ecken ist die Sockelleiste mittels Gehrungs- oder Kappsäge zuzuschneiden. Schneiden Sie stets nur die Leiste welche Sie auch direkt anmontieren wollen.

Befestigung der Leiste:

Nageln Sie die Leiste ggf. mittels Stahlstiften welche nicht rosten sollten in einem Abstand von ca. 30 cm an. Wenn Sie es vorziehen die Leiste zu kleben, empfehlen wir einen Montagekleber mit hoher Anfangshaftung oder ein stark haftendes doppelseitiges Klebeband. Nach Befestigung der Leiste kann nun mit dem Einlegen des Bodenbelagsstreifens begonnen werden. Schneiden Sie den Bodenbelagsstreifen entsprechend der Höhe der Leiste vom Bodenbelag aus gerechnet zu. Ggf. müssen Sie den entstandenen Spalt mit einem weiteren Klebeband bekleben. Entfernen Sie das Schutzpapier vom Klebeband und legen Sie den Streifen des Bodenbelags passend am Anfang an und drücken diesen fest in die Leiste. Reiben Sie nun den Bodenbelag gut auf das Klebeband an und vergewissern Sie sich das keine Falten oder Knicke zurückgeblieben sind.

Preparation:

The skirting board is attached to the wall by nailing, clinging or gluing. The wall and the floor should be as levelled as possible. Begin by the door frame and work in a clockwise direction.

Cutting the skirting boards:

At the end or at the corners the skirting board has to be cut by a miter or chop saw. Always cut only the skirting which you want to mount directly.

Attachment of the skirting:

If necessary, nail the strip with steel pins which should not rust at a distance of approx. 30 cm. If you prefer to glue the profile, we recommend a mounting adhesive with high initial adhesion or a strong adhesive double sided tape. After fixing the skirting you can start with the insertion of the flooring strip. Cut the flooring according to the height of the skirting from the floor covering. Remove the protective paper from the tape and place the strip of flooring properly at the beginning and press it firmly into the bar. Now rub the flooring well onto the tape and make sure that no wrinkles or creases are left behind.

